

FIELD SERVICE BULLETIN

Subject: Rigging or moving walk in ovens

Note: Rigging should be performed by qualified personnel only

First method for rigging:

There are gaps to slide the fork lift into. With ovens of this size our craters told me you might want to lift them up a little bit first so you can get a 2 x 4 under each corner. This will enable you to slide the forks further under the oven to lift it up off the skid.

After you remove the skid from under the oven you can set the oven on blocks in the area you want to set it. Keeping it on the blocks will help make it easier to get forks under it and fine tune the placement. When you have it where you want it you can lift one side at a time and remove the blocks.

Second rigging method:

If you have overhead access that can handle the weight, say 8000 lbs., we could add lifting lugs to the top of the ovens. You do need a lot of overhead room if you use this method.