

Preventative Maintenance

Each application is different as is each piece of equipment is different, making a standard Preventive Maintenance (PM) program impossible. We at Despatch can research and develop a PM program for your equipment and application.

Sample PM Schedule

Item Description	Reading or Setting	Months Of Operation				
		1	3	6	9	12
Measure and record the line and control voltages — if the voltage is +/-10% of the specification on the equipment nameplate discontinue use and take corrective action.	L1=					X
	L2=					
	L3=					
	X1=					
Measure and record recirculation fan motor amps — will give a rough indication of fan efficiency, a reduction in motor amps of more than 15% at ambient temperature, could indicate improper loading or a restriction in the recirculation blower fan or duct work.	T1=					X
	T2=					
	T3=					

ALTERNATIVES - After the program is defined per above.

- We could have one of our Despatch Supported Field Service Representatives visit your location to perform the PM program at an hourly charge.
- We could provide on-site supervision and training for your maintenance and operations personnel as they perform the PM program at an hourly charge.
- We could provide you with a PM or Full Service agreement. These contracts can be quoted on semi-annual or annual basis.

We hope you will find this information useful. THANK YOU for contacting us and allowing us to be a service to you. Please contact us at 1-800-473-7373 if you have any questions.